



Tomahawk Live Trap llc

www.livetraps.com

Manufacturing Traps and Cages Since 1925

**Po Box 155, Hazelhurst, WI 54531 • trapem@livetraps.com
800-272-8727 • Customer Service: 715-356-4600 • Fax: 715-356-4611**

DuraFlex Net Assembly Instructions

Components List

- Aluminum shaft with black grip attached.
- 2 - 3/8" screws inserted on the Y end of the pole.
- White nylon rod.
- Nylon Net
- Net tie off rope already threaded in net.
- Plastic tie-off ring already attached to the rope.



DuraFlex nets are designed for flexibility enabling you to trap animals on the ground or other objects.

Step 1

Threading Nylon Rod Through Net

This step is much easier with two people; one for bending the nylon rod and one for threading the net. Begin by pushing one end of the nylon rod into the hem at the top of the net as far as it will go. Place the free end of the rod against your waste and bend the nylon rod into a C shape. ****CAUTION the nylon rod will snap back with great force to its original shape if you let go before it is completely threaded**** You should now be able to thread the nylon rod through the rest of the net or have a second person help you. After the nylon rod is completely threaded there should be two to four inches protruding from each end.

Step 2

Attaching the Net to the Aluminum Shaft

Begin by feeding the grip end of the shaft through the plastic tie-off ring attached to the net. Remove the two screws on the Y end of the shaft. Push the two ends of the nylon rod into the openings on the Y end of the shaft as far as they will go in. In the position where screws were removed use a one eighth inch drill bit to pre-drill holes into the nylon hoop about a quarter inch deep. Insert the screws into your predrilled holes making them tight but do not strip the nylon hoop by over tightening.

Thank you for your purchase!

Please call our customer service at 715-356-4600 with any questions or concerns.